

CONTACTOR

Contactor 3P Type Baru

NAMA KOMPONEN		PHASE	BRAND	TYPE
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-9b 220 1A1B
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-12b 220 1A1B
CONTACTOR 3P 32A AC1, 18A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-18b 220 1A1B
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-22b 220 1A1B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-32a 220 2A2B
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-40a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 100A AC1, 65A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-65a 220 2A2B
CONTACTOR 3P 110A AC1, 75A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-75a 220 2A2B
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
CONTACTOR 3P 160A AC1, 130A AC3 415V	Coil 240VAC	3P	TERASAKI	TC 130a 240 2A2B
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-225a 240 2A2B
CONTACTOR 3P 300A AC1, 265A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-265a 240 2A2B
CONTACTOR 3P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-330a 240 2A2B
CONTACTOR 3P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-400a 240 2A2B
CONTACTOR 3P 580A AC1, 500A AC3 415V	Coil 200 VAC/VDC	3P	TERASAKI	TC-500a 200 2A2B
CONTACTOR 3P 660A AC1, 630A AC3 415V	Coil 200 VAC/VDC	3P	TERASAKI	TC-630a 200 2A2B
CONTACTOR 3P 900A AC1, 800A AC3 415V	Coil 200 VAC/VDC	3P	TERASAKI	TC-800a 200 2A2B

Contactor 4P Type Baru

NAMA KOMPONEN		PHASE	BRAND	TYPE
CONTACTOR 4P 25A AC1, 9A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-9b 220 1A / 1B
CONTACTOR 4P 25A AC1, 12A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-12b 220 1A / 1B
CONTACTOR 4P 32A AC1, 18A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-18b 220 1A / 1B
CONTACTOR 4P 40A AC1, 22A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-22b 220 1A / 1B
CONTACTOR 4P 50A AC1, 32A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-32a 220 1A / 1B
CONTACTOR 4P 60A AC1, 40A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-40a 220 1A / 1B
CONTACTOR 4P 70A AC1, 55A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-50a 220 1A / 1B
CONTACTOR 4P 100A AC1, 65A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-65a 220 1A / 1B
CONTACTOR 4P 110A AC1, 75A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-75a 220 1A / 1B
CONTACTOR 4P 135A AC1, 85A AC3 415V	Coil 220VAC	4P	TERASAKI	TC4-85a 220 1A / 1B
CONTACTOR 4P 160A AC1, 105A AC3 415V	Coil 240VAC	4P	TERASAKI	TC4-100a 240 1A / 1B
CONTACTOR 4P 160A AC1, 130A AC3 415V	Coil 240VAC	4P	TERASAKI	TC4-130a 240 2A2B
CONTACTOR 4P 210A AC1, 150A AC3 415V	Coil 240VAC	4P	TERASAKI	TC4-150a 240 2A2B
CONTACTOR 4P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	4P	TERASAKI	TC4-185a 240 2A2B
CONTACTOR 4P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	4P	TERASAKI	TC4-225a 240 2A2B
CONTACTOR 4P 300A AC1, 265A AC3 415V	Coil 100 - 240 VAC/VDC	4P	TERASAKI	TC4-265a 240 2A2B
CONTACTOR 4P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	4P	TERASAKI	TC4-330a 240 2A2B
CONTACTOR 4P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	4P	TERASAKI	TC4-400a 240 2A2B
CONTACTOR 4P 580A AC1, 500A AC3 415V	Coil 200 VAC/VDC	4P	TERASAKI	TC4-500a 200 2A2B
CONTACTOR 4P 660A AC1, 630A AC3 415V	Coil 200 VAC/VDC	4P	TERASAKI	TC4-630a 200 2A2B
CONTACTOR 4P 900A AC1, 800A AC3 415V	Coil 200 VAC/VDC	4P	TERASAKI	TC4-800a 200 2A2B

Contactor 3P Type Baru DC Coil

NAMA KOMPONEN		PHASE	BRAND	TYPE
CONTACTOR 3P 25A AC1, 9A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-9bD 1A1B
CONTACTOR 3P 25A AC1, 12A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-12bD 1A1B
CONTACTOR 3P 32A AC1, 18A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-18bD 1A1B
CONTACTOR 3P 40A AC1, 22A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-22bD 1A1B
CONTACTOR 3P 50A AC1, 32A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-32aD 2A2B
CONTACTOR 3P 60A AC1, 40A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-40aD 2A2B
CONTACTOR 3P 70A AC1, 55A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-50aD 2A2B



CONTACTOR 3P 100A AC1, 65A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-65aD 2A2B
CONTACTOR 3P 110A AC1, 75A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-75aD 2A2B
CONTACTOR 3P 135A AC1, 85A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-85aD 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	12/20/24/48/60/80/100/110/125/200/220/250 VDC	3P	TERASAKI	TC-100aD 2A2B
CONTACTOR 3P 160A AC1, 130A AC3 415V	24/48/110/220 VDC	3P	TERASAKI	TC 130aD 2A2B
CONTACTOR 3P 210A AC1, 150A AC3 415V	24/48/110/220 VDC	3P	TERASAKI	TC-150aD 2A2B

THERMAL OVERLOAD RELAY

Thermal Overload Relay TK32a

NAMA KOMPONEN	PHASE	BRAND	TYPE
THERMAL OVER LOAD TK32a (0,1-0,16) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 0.16A
THERMAL OVER LOAD TK32a (0,16-0,25) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 0.25A
THERMAL OVER LOAD TK32a (0,25-0,4) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 0.4A
THERMAL OVER LOAD TK32a (0,4-0,63) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 0.63A
THERMAL OVER LOAD TK32a (0,63-1) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 1.0A
THERMAL OVER LOAD TK32a (1-1,6) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 1.6A
THERMAL OVER LOAD TK32a (1,6-2,5) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 2.5A
THERMAL OVER LOAD TK32a (2,5-4) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 4A
THERMAL OVER LOAD TK32a (4-6) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 6A
THERMAL OVER LOAD TK32a (5-8) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 8A
THERMAL OVER LOAD TK32a (6-9) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 9A
THERMAL OVER LOAD TK32a (7-10) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 10A
THERMAL OVER LOAD TK32a (9-13) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 13A
THERMAL OVER LOAD TK32a (12-18) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 18A
THERMAL OVER LOAD TK32a (16-22) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 22A
THERMAL OVER LOAD TK32a (18-25) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 25A
THERMAL OVER LOAD TK32a (22-32) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 32A
THERMAL OVER LOAD TK32a (28-40) for TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 40A

Thermal Overload Relay TK63a

NAMA KOMPONEN	PHASE	BRAND	TYPE
THERMAL OVER LOAD TK63a (24-36) for TC50a/TC65a	3P	TERASAKI	TK63a- 36A
THERMAL OVER LOAD TK63a (28-40) for TC50a/TC65a	3P	TERASAKI	TK63a- 40A
THERMAL OVER LOAD TK63a (34-50) for TC50a/TC65a	3P	TERASAKI	TK63a- 50A
THERMAL OVER LOAD TK63a (45-65) for TC50a/TC65a	3P	TERASAKI	TK63a- 65A

Thermal Overload Relay TK95a

NAMA KOMPONEN	PHASE	BRAND	TYPE
THERMAL OVER LOAD TK95a (45-65) for TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 65A
THERMAL OVER LOAD TK95a (54-75) for TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 75A
THERMAL OVER LOAD TK95a (63-85) for TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 85A
THERMAL OVER LOAD TK95a (70-95) for TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 95A
THERMAL OVER LOAD TK95a (80-100) for TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 100A

Thermal Overload Relay TK150a

NAMA KOMPONEN	PHASE	BRAND	TYPE



THERMAL OVER LOAD TK150a (80-105)	for TC130a/TC150a	3P	TERASAKI	TK150a- 100A
THERMAL OVER LOAD TK150a (95-130)	for TC130a/TC150a	3P	TERASAKI	TK150a- 130A
THERMAL OVER LOAD TK150a (110-150)	for TC130a/TC150a	3P	TERASAKI	TK150a- 150A

Thermal Overload Relay TK225a

NAMA KOMPONEN		PHASE	BRAND	TYPE
THERMAL OVER LOAD TK225a (85-125)	for TC185a/TC225a	3P	TERASAKI	TK225a- 125A
THERMAL OVER LOAD TK225a (100-160)	for TC185a/TC225a	3P	TERASAKI	TK225a- 160A
THERMAL OVER LOAD TK225a (120-185)	for TC185a/TC225a	3P	TERASAKI	TK225a- 185A
THERMAL OVER LOAD TK225a (160-240)	for TC185a/TC225a	3P	TERASAKI	TK225a- 240A

Thermal Overload Relay TK400a

NAMA KOMPONEN		PHASE	BRAND	TYPE
THERMAL OVER LOAD TK400a (85-125)	for TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 125A
THERMAL OVER LOAD TK400a (160-240)	for TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 240A
THERMAL OVER LOAD TK400a (200-330)	for TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 330A
THERMAL OVER LOAD TK400a (260-400)	for TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 400A

Thermal Overload Relay TK800a

NAMA KOMPONEN		PHASE	BRAND	TYPE
THERMAL OVER LOAD TK800a (260-400)	for TC500a/TC630a/TC800a	3P	TERASAKI	TK800a- 400A
THERMAL OVER LOAD TK800a (400-600)	for TC500a/TC630a/TC800a	3P	TERASAKI	TK800a- 600A
THERMAL OVER LOAD TK800a (520-800)	for TC500a/TC630a/TC800a	3P	TERASAKI	TK800a- 800A

AUXILIARY CONTACT

NAMA KOMPONEN		PHASE	BRAND	TYPE
AUXILIARY CONTACT 1 NO 1 NC (Top Mounting)	for TC9a ~ TC150a	2P	TERASAKI	TSU-11
AUXILIARY CONTACT 2 NO 0 NC (Top Mounting)	for TC9a ~ TC150a	2P	TERASAKI	TSU-20
AUXILIARY CONTACT 0 NO 2 NC (Top Mounting)	for TC9a ~ TC150a	2P	TERASAKI	TSU-02
AUXILIARY CONTACT 2 NO 2 NC (Top Mounting)	for TC9a ~ TC150a	4P	TERASAKI	TSU-22
AUXILIARY CONTACT 3 NO 1 NC (Top Mounting)	for TC9a ~ TC150a	4P	TERASAKI	TSU-31
AUXILIARY CONTACT 1 NO 3 NC (Top Mounting)	for TC9a ~ TC150a	4P	TERASAKI	TSU-13
AUXILIARY CONTACT 4 NO 0 NC (Top Mounting)	for TC9a ~ TC150a	4P	TERASAKI	TSU-40
AUXILIARY CONTACT 0 NO 4 NC (Top Mounting)	for TC9a ~ TC150a	4P	TERASAKI	TSU-04
AUXILIARY CONTACT 1 NO 1 NC (Side Mounting)	for TC9a ~ TC150a	2P	TERASAKI	TSU-1
AUXILIARY CONTACT 1 NO 1 NC (Side Mounting)	for TC185a ~ TC800a	2P	TERASAKI	TSU-100

MECHANICAL INTERLOCK

NAMA KOMPONEN		PHASE	BRAND	TYPE
MECHANICAL INTERLOCK	for TC9b ~ TC150a		TERASAKI	TSR-02
MECHANICAL INTERLOCK	for TC185a ~ TC400a		TERASAKI	TKA-180
MECHANICAL INTERLOCK	for TC600a ~ TC800a		TERASAKI	TKA-600

MECHANICAL LATCH UNIT

NAMA KOMPONEN	PHASE	BRAND	TYPE
MECHANICAL LATCH UNIT for TC9 ~ TC40		TERASAKI	TSL-65
MECHANICAL LATCH UNIT for TC50 ~ TC85		TERASAKI	TSL-150

SURGE ABSORBER

NAMA KOMPONEN	PHASE	BRAND	TYPE
SURGE ABSORBER VARISTOR, AC/DC24~48V for TC(D)-9 ~ TKC800		TERASAKI	TSS-11
SURGE ABSORBER VARISTOR, AC/DC100~125V for TC(D)-9 ~ TKC801		TERASAKI	TSS-12
SURGE ABSORBER VARISTOR, AC/DC200~240V for TC(D)-9 ~ TKC802		TERASAKI	TSS-13
SURGE ABSORBER VARISTOR, AC/DC380~440V for TC(D)-9 ~ TKC803		TERASAKI	TSS-14
SURGE ABSORBER CR+VARISTOR, AC24~48V for TC9 ~ TC85		TERASAKI	TSS-1
SURGE ABSORBER CR+VARISTOR, AC100~125V for TC9 ~ TC86		TERASAKI	TSS-2
SURGE ABSORBER CR+VARISTOR, AC200~240V for TC9 ~ TC87		TERASAKI	TSS-3
SURGE ABSORBER CR+VARISTOR, DC24~48V for TC9 ~ TC88		TERASAKI	TSS-4
SURGE ABSORBER CR+VARISTOR, DC100~125V for TC9 ~ TC89		TERASAKI	TSS-5
SURGE ABSORBER CR+VARISTOR, DC200~220V for TC9 ~ TC90		TERASAKI	TSS-6

ELECTRIC CONTACTOR RELAY

NAMA KOMPONEN	PHASE	BRAND	TYPE
ELECTRIC CONTACTOR RELAY AC2NO2NC COIL 220 VAC	4P	TERASAKI	TR-22...2A2B
ELECTRIC CONTACTOR RELAY AC3NO1NC COIL 220 VAC	4P	TERASAKI	TR-31...3A1B
ELECTRIC CONTACTOR RELAY AC1 NO3NC COIL 220 VAC	4P	TERASAKI	TR-13...1A3B
ELECTRIC CONTACTOR RELAY AC4NO0NC COIL 220 VAC	4P	TERASAKI	TR-40...4A
ELECTRIC CONTACTOR RELAY AC0NO4NC COIL 220 VAC	4P	TERASAKI	TR-04...4B
ELECTRIC CONTACTOR RELAY DC 2NO2NC COIL 24 VDC	4P	TERASAKI	TR-22D...2A2B
ELECTRIC CONTACTOR RELAY DC 3NO1NC COIL 24 VDC	4P	TERASAKI	TR-31D...3A1B
ELECTRIC CONTACTOR RELAY DC 1NO3NC COIL 24 VDC	4P	TERASAKI	TR-13D...1A3B
ELECTRIC CONTACTOR RELAY DC 4NO0NC COIL 24 VDC	4P	TERASAKI	TR-40D...4A
ELECTRIC CONTACTOR RELAY DC 0NO4NC COIL 24 VDC	4P	TERASAKI	TR-04D...4B

CAPACITOR PROPERTIES

NAMA KOMPONEN	PHASE	BRAND	TYPE
<u>CAPACITOR UNIT</u>			
FOR TC 9-40		TERASAKI	TKM 9
FOR TC 50-85		TERASAKI	TKM 50
<u>CONTACTOR FOR CAPACITOR</u>			
CONTACTOR 3P 20A AC1, 9A (For 10kVAR)	3P	TERASAKI	TC9b+TKM9
CONTACTOR 3P 20A AC1, 12A (For 12,5kVAR)	3P	TERASAKI	TC12b+TKM9
CONTACTOR 3P 25A AC1, 18A (For 16,7kVAR)	3P	TERASAKI	TC18b+TKM9
CONTACTOR 3P 32A AC1, 22A (For 18kVAR)	3P	TERASAKI	TC22a+TKM9
CONTACTOR 3P 50A AC1, 32A (For 23kVAR)	3P	TERASAKI	TC32a+TKM9
CONTACTOR 3P 60A AC1, 40A (For 30kVAR)	3P	TERASAKI	TC40a+TKM9
CONTACTOR 3P 80A AC1, 50A (For 40kVAR)	3P	TERASAKI	TC-50a+TKM50



CONTACTOR 3P 100A AC1, 65A (For 45kVAR)		3P	TERASAKI	TC-65a+TKM50
CONTACTOR 3P 110A AC1, 75A (For 50kVAR)		3P	TERASAKI	TC-75a+TKM50
CONTACTOR 3P 135A AC1, 85A (For 60kVAR)		3P	TERASAKI	TC-85a+TKM50
<i>DIRECT ON LINE (DOL)</i>				
<i>DIRECT ON LINE (DOL) 0,2 KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (0,63-1)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 1.0A
<i>DIRECT ON LINE (DOL) 0,4 KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (1-1,6)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 1.6A
<i>DIRECT ON LINE (DOL) 0,75KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (1,6-2,5)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 2.5A
<i>DIRECT ON LINE (DOL) 1 KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (2,5-4)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 4A
<i>DIRECT ON LINE (DOL) 1,5 KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (2,5-4)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 4A
<i>DIRECT ON LINE (DOL) 2,2 KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (4-6)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 6A
<i>DIRECT ON LINE (DOL) 3,7 KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (4-6)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 6A
<i>DIRECT ON LINE (DOL) 4KW</i>				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (7-10)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 10A
<i>DIRECT ON LINE (DOL) 5,5KW</i>				
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
THERMAL OVER LOAD TK32a (9-13)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 13A
<i>DIRECT ON LINE (DOL) 7,5 KW</i>				
CONTACTOR 3P 32A AC1, 18A AC3 415V	Coil 220VAC	3P	TERASAKI	TC18b 220 1A1B
THERMAL OVER LOAD TK32a (12-18)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 18A
<i>DIRECT ON LINE (DOL) 11 KW</i>				
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
THERMAL OVER LOAD TK32a (16-22)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 22A
<i>DIRECT ON LINE (DOL) 15KW</i>				
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
THERMAL OVER LOAD TK32a (22-32)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 32A
<i>DIRECT ON LINE (DOL) 18,5KW</i>				
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC40a 220 2A2B
THERMAL OVER LOAD TK32a (28-40)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 40A
<i>DIRECT ON LINE (DOL) 22KW</i>				
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
THERMAL OVER LOAD TK63a (34-50)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 50A
<i>DIRECT ON LINE (DOL) 30KW</i>				
CONTACTOR 3P 100A AC1, 65A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-65a 220 2A2B
THERMAL OVER LOAD TK63a (45-65)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 65A
<i>DIRECT ON LINE (DOL) 37KW</i>				
CONTACTOR 3P 110A AC1, 75A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-75a 220 2A2B
THERMAL OVER LOAD TK95a (54-75)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 75A

<i>DIRECT ON LINE (DOL) 45KW</i>				
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B



THERMAL OVER LOAD TK95a (63-85)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 85A
DIRECT ON LINE (DOL) 55KW				
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
THERMAL OVER LOAD TK95a (80-100)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 100A
DIRECT ON LINE (DOL) 60KW				
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
THERMAL OVER LOAD TK150a (95-130)	FOR TC130a/TC150a	3P	TERASAKI	TK150a- 130A
DIRECT ON LINE (DOL) 75KW				
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
THERMAL OVER LOAD TK150a (110-150)	FOR TC130a/TC150a	3P	TERASAKI	TK150a- 150A
DIRECT ON LINE (DOL) 90KW				
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
THERMAL OVER LOAD TK225a (120-185)	FOR TC185a/TC225a	3P	TERASAKI	TK225a- 185A
DIRECT ON LINE (DOL) 132KW				
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B
THERMAL OVER LOAD TK225a (160-240)	FOR TC185a/TC225a	3P	TERASAKI	TK225a- 240A
DIRECT ON LINE (DOL) 147 KW				
CONTACTOR 3P 300A AC1, 265A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC265a 240 2A2B
THERMAL OVER LOAD TK400a (200-330)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 330A
DIRECT ON LINE (DOL) 160KW				
CONTACTOR 3P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-330a 240 2A2B
THERMAL OVER LOAD TK400a (200-330)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 330A
DIRECT ON LINE (DOL) 200KW				
CONTACTOR 3P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-400a 240 2A2B
THERMAL OVER LOAD TK400a (260-400)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 400A
<u>STAR DELTA STARTER</u>				
STAR DELTA STARTER 4 KW				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (4-6)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 6A
STAR DELTA STARTER 5,5 KW				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (5-8)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 8A
STAR DELTA STARTER 7,5 KW				
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (7-10)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 10A
STAR DELTA STARTER 11 KW				
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
CONTACTOR 3P 25A AC1, 9A AC3 415V	Coil 220VAC	3P	TERASAKI	TC9b 220 1A1B
THERMAL OVER LOAD TK32a (9-13)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 13A
STAR DELTA STARTER 15 KW				
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
THERMAL OVER LOAD TK32a (12-18)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 18A
STAR DELTA STARTER 18,5 KW				
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
CONTACTOR 3P 32A AC1, 18A AC3 415V	Coil 220VAC	3P	TERASAKI	TC18b 220 1A1B
THERMAL OVER LOAD TK32a (16-22)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 22A
STAR DELTA STARTER 22KW				
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B



CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
CONTACTOR 3P 32A AC1, 18A AC3 415V	Coil 220VAC	3P	TERASAKI	TC18b 220 1A1B
THERMAL OVER LOAD TK32a (18-25)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 25A
STAR DELTA STARTER 30KW		3P		
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC40a 220 2A2B
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC40a 220 2A2B
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
THERMAL OVER LOAD TK32a (22-32)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 32A
STAR DELTA STARTER 37KW		3P		
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
THERMAL OVER LOAD TK63a (28-40)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 40A

STAR DELTA STARTER 45KW		3P		
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
THERMAL OVER LOAD TK63a (34-50)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 50A

STAR DELTA STARTER 55KW		3P		
CONTACTOR 3P 100A AC1, 65A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-65a 220 2A2B
CONTACTOR 3P 100A AC1, 65A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-65a 220 2A2B
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC40a 220 2A2B
THERMAL OVER LOAD TK63a (45-65)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 65A

STAR DELTA STARTER 75KW		3P		
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
THERMAL OVER LOAD TK95a (63-85)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 85A

STAR DELTA STARTER 90KW		3P		
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
CONTACTOR 3P 100A AC1, 65A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-65a 220 2A2B
THERMAL OVER LOAD TK95a (80-100)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 100A

STAR DELTA STARTER 110KW		3P		
CONTACTOR 3P 160A AC1, 130A AC3 415V	Coil 240VAC	3P	TERASAKI	TC 130a 240 2A2B
CONTACTOR 3P 160A AC1, 130A AC3 415V	Coil 240VAC	3P	TERASAKI	TC 130a 240 2A2B
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
THERMAL OVER LOAD TK150a (95-130)	FOR TC130a/TC150a	3P	TERASAKI	TK150a- 130A

STAR DELTA STARTER 132KW		3P		
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
THERMAL OVER LOAD TK150a (110-150)	FOR TC130a/TC150a	3P	TERASAKI	TK150a- 150A

STAR DELTA STARTER 160KW		3P		
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
THERMAL OVER LOAD TK225a (120-185)	FOR TC185a/TC225a	3P	TERASAKI	TK225a- 185A

STAR DELTA STARTER 200KW		3P		
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
THERMAL OVER LOAD TK225a (160-240)	FOR TC185a/TC225a	3P	TERASAKI	TK225a- 240A

STAR DELTA STARTER 250KW		3P		
CONTACTOR 3P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-330a 240 2A2B
CONTACTOR 3P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-330a 240 2A2B
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
THERMAL OVER LOAD TK400a (200-330)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 330A

STAR DELTA STARTER 315KW		3P		
CONTACTOR 3P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-400a 240 2A2B
CONTACTOR 3P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-400a 240 2A2B
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B



THERMAL OVER LOAD TK400a (260-400)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 400A
AUTO TRANSFORMER MOTOR STARTERS				
Auto Transformer Motor Starters 11 KW		3P		
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
THERMAL OVER LOAD TK32a (16-22)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 22A
Auto Transformer Motor Starters 15 KW		3P		
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
THERMAL OVER LOAD TK32a (22-32)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 32A
Auto Transformer Motor Starters 18.5 KW		3P		
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC40a 220 2A2B
CONTACTOR 3P 60A AC1, 40A AC3 415V	Coil 220VAC	3P	TERASAKI	TC40a 220 2A2B
CONTACTOR 3P 25A AC1, 12A AC3 415V	Coil 220VAC	3P	TERASAKI	TC12b 220 1A1B
THERMAL OVER LOAD TK32a (28-40)	FOR TC9b /TC12b/TC12b/TC22b/TC32b/TC40b	3P	TERASAKI	TK32a- 40A
Auto Transformer Motor Starters 22 KW		3P		
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
CONTACTOR 3P 32A AC1, 18A AC3 415V	Coil 220VAC	3P	TERASAKI	TC18b 220 1A1B
THERMAL OVER LOAD TK63a (34-50)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 50A
Auto Transformer Motor Starters 30 KW		3P		
CONTACTOR 3P 100A AC1, 65A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-65a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 40A AC1, 22A AC3 415V	Coil 220VAC	3P	TERASAKI	TC22b 220 1A1B
THERMAL OVER LOAD TK63a (45-65)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 65A
Auto Transformer Motor Starters 37 KW		3P		
CONTACTOR 3P 110A AC1, 75A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-75a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
THERMAL OVER LOAD TK63a (45-65)	FOR TC50a/TC65a	3P	TERASAKI	TK63a- 65A
Auto Transformer Motor Starters 45 KW		3P		
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
THERMAL OVER LOAD TK95a (63-85)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 85A
Auto Transformer Motor Starters 55 KW		3P		
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
CONTACTOR 3P 50A AC1, 32A AC3 415V	Coil 220VAC	3P	TERASAKI	TC32a 220 2A2B
THERMAL OVER LOAD TK95a (80-100)	FOR TC75a/TC85a/TC100a	3P	TERASAKI	TK95a- 100A
Auto Transformer Motor Starters 75 KW		3P		
CONTACTOR 3P 210A AC1, 150A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-150a 240 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
THERMAL OVER LOAD TK150a (110-150)	FOR TC130a/TC150a	3P	TERASAKI	TK150a- 150A
Auto Transformer Motor Starters 90 KW		3P		
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
CONTACTOR 3P 160A AC1, 130A AC3 415V	Coil 240VAC	3P	TERASAKI	TC 130a 240 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
THERMAL OVER LOAD TK225a (120-185)	FOR TC185a/TC225a	3P	TERASAKI	TK225a- 185A
Auto Transformer Motor Starters 110 KW		3P		
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
CONTACTOR 3P 70A AC1, 50A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-50a 220 2A2B
THERMAL OVER LOAD TK225a (160-240)	FOR TC185a/TC225a	3P	TERASAKI	TK225a- 240A
Auto Transformer Motor Starters 132 KW		3P		
CONTACTOR 3P 300A AC1, 265A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC265a 240 2A2B
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B



CONTACTOR 3P 135A AC1, 85A AC3 415V	Coil 220VAC	3P	TERASAKI	TC-85a 220 2A2B
THERMAL OVER LOAD TK400a (200-330)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 330A
Auto Transformer Motor Starters 160 KW		3P		
CONTACTOR 3P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-330a 240 2A2B
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B
CONTACTOR 3P 160A AC1, 105A AC3 415V	Coil 240VAC	3P	TERASAKI	TC-100a 240 2A2B
THERMAL OVER LOAD TK400a (200-330)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 330A
Auto Transformer Motor Starters 200 KW		3P		
CONTACTOR 3P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-400a 240 2A2B
CONTACTOR 3P 350A AC1, 330A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-330a 240 2A2B
CONTACTOR 3P 160A AC1, 130A AC3 415V	Coil 240VAC	3P	TERASAKI	TC 130a 240 2A2B
THERMAL OVER LOAD TK400a (260-400)	FOR TC265a/TC300a/TC400a	3P	TERASAKI	TK400a- 400A
Auto Transformer Motor Starters 250 KW		3P		
CONTACTOR 3P 660A AC1, 630A AC3 415V	Coil 200 VAC/VDC	3P	TERASAKI	TC-630a 200 2A2B
CONTACTOR 3P 450A AC1, 400A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-400a 240 2A2B
CONTACTOR 3P 230A AC1, 185A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC-185a 240 2A2B
THERMAL OVER LOAD TK800a (400-600)	FOR TC500a/TC630a/TC800a	3P	TERASAKI	TK800a- 600A
Auto Transformer Motor Starters 315 KW		3P		
CONTACTOR 3P 660A AC1, 630A AC3 415V	Coil 200 VAC/VDC	3P	TERASAKI	TC-630a 200 2A2B
CONTACTOR 3P 660A AC1, 630A AC3 415V	Coil 200 VAC/VDC	3P	TERASAKI	TC-630a 200 2A2B
CONTACTOR 3P 275A AC1, 225A AC3 415V	Coil 100 - 240 VAC/VDC	3P	TERASAKI	TC225a 240 2A2B
THERMAL OVER LOAD TK800a (400-600)	FOR TC500a/TC630a/TC800a	3P	TERASAKI	TK800a- 600A